

DIAMOND BODY 36 INSTRUCTIONS

1 PREP THE SURFACE

Ensure all vehicle elements are wiped down with **DIAMOND BODY PREP**.



2 SHAKE THE BOTTLE

Shake **DIAMOND BODY 36** well for 15 seconds or longer. Place 15-20 drops to an applicator to prime it.



3 APPLY COATING

Apply the coating to 1-2 elements of the car in a crosshatch fashion. Re-apply several more drops of product to the applicator as needed.



4 WAIT & WIPE

Wait 1-3 minutes, then wipe off the excess coating. Try to look for a hazing effect indicating the coating is ready to be wiped off.

(Wipe off time may vary due to ambient temperature, humidity, and substrate type.)



INSTALLATION TIPS

- For use on all body panels, plastic trim, headlights, and chrome accents.
- Do NOT use on glass.
- Use separate microfiber towels for wiping off **Diamond Body Prep** & **Diamond Body 36**.
- Polishing is not required before application, but is strongly recommended.
- If you experience a high spot while coating, re-apply **Diamond Body 36** to the affected surface & immediately wipe off.

SCAN TO WATCH INSTRUCTION VIDEO!

