

1 PREP THE SURFACE

Ensure Leather is wiped down with DIAMOND BODY PREP.



(3) APPLY COATING

Apply the coating evenly to the surface. Re-apply additional drops of product to the applicator as needed.

(2) SHAKE THE BOTTLE

Shake DIAMOND LEATHER well for 15 seconds or longer. Apply 15-20 drops onto an applicator to prime it.



(4) WAIT & WIPE

Wait 30 seconds - 1 minute, then buff off excess coating with a microfiber towel.



INSTALLATION TIPS

- · For use on all types of leather.
- Use separate microfiber towels for wiping off **Diamond Body Prep** & **Diamond Leather**.
- If you experience a high spot while coating, wipe the surface with **Diamond Body Prep**.

SCAN TO WATCH INSTRUCTION VIDEO!

