

# PRO HYDRO<sup>2</sup> INSTRUCTIONS

## 1 PREP THE SURFACE

Ensure all vehicle elements are wiped down with **DIAMOND BODY PREP**.



## 2 SHAKE THE BOTTLE

Shake **PRO 120A**, **PRO120B**, and **PRO HYDRO<sup>2</sup>** well for 15 seconds or longer, respectively. Place 15-20 drops to an applicator to prime each product.



## 3 APPLY COATING

Apply the respective coating to 1-2 elements of the car in a crosshatch fashion. Re-apply additional drops of product to the applicator as needed.



## 4 WAIT & WIPE

For **PRO 120A**, wait 1-3 minutes, then wipe off the excess coating. Try to look for a hazing effect indicating the coating is ready to be wiped off.  
1 Hour after beginning **PRO 120A**, begin **PRO 120B**.  
For **PRO 120B**, wait 1-3 minutes, then wipe off the excess coating. Try to look for lines and droplets indicating the coating is ready for wipe-off.  
1 Hour after beginning **PRO 120B**, begin **PRO Hydro<sup>2</sup>**.  
For **PRO HYDRO<sup>2</sup>**, wait 3-5 minutes, then wipe off the excess coating. Try to look for lines and droplets indicating the coating is ready for wipe-off.  
(Wipe off time may vary due to ambient temperature, humidity and substrate type.)



## INSTALLATION TIPS

- For use on all body panels, plastic trim, headlights, and chrome accents.
- Do NOT use on glass.
- Use separate microfiber towels for wiping off **Diamond Body Prep**, **PRO 120A**, **PRO 120B** and **PRO Hydro<sup>2</sup>**.
- Polishing is not required before application, but is strongly recommended.
- If you experience a high spot while coating, re-apply **PRO 120A**, **PRO 120B** or **PRO Hydro<sup>2</sup>** to the affected surface & immediately wipe off.

## SCAN TO WATCH INSTRUCTION VIDEO!

